

How-to Video Series

How to properly use Promatch® Vivid Spray Stains

Vivid Spray stains are an easy one step, no wipe, color method. Versatile use of pigments and dyes make C-Mix Vivid Spray Stain a user friendly option.

Certain woods lend themselves well to one step spray stains. Choosing to use a pigmented spray stain depends on the target color and desired look. Pigmented spray stains render a uniform appearance. Pigmented spray stains are prepared using Vivid Spray Stain base and universal tints.

Steps

- 01. Be sure to stir your C-Mix Vivid Spray Stain thoroughly to ensure color consistency.
- **02.** Spray a uniform wet coat of C-Mix Vivid Spray Stain following the direction of the grain to minimize striping. Be sure to maintain the same distance from the wood on each pass. Spray with the grain, overlapping passes approximately 50% to insure uniform coverage.
- **03.** The color and effect can be altered by the amount applied or by atomizing air and fluid pressure. To enhance the contrast of the grain, a wetter coat should be applied. This can be achieved with less atomizing air pressure and higher fluid pressure.
- **04.** If a more uniform or less grain contrast is desired, then use higher atomizing air and less fluid pressure.
- **05.** Allow to flash as specified on the Product Information Sheet, before sealing. Dark stains will take slightly longer to dry.

Spray stains will dry faster and reduce labor, allowing for faster production time.

[•] Remember to always wear appropriate Personal Protective Equipment

[•] Always refer to your (MSDS) Material Safety Data Sheet for proper (PPE) Personal Protective Equipment.